



delabs design
 delabs-circuits.com
 delabs.net
 Intellectual Property



T1
 Transformer
 Pri 40 turns 36 awg
 Sec 90 turns 36 awg
 wind pri first
 Insulation tape between pri and s
 wind sec next
 cover final sec with tape
 Pot core HK100 CL
 18mm dia 10mm ht
 Use a pot core clamp
 or nylon nut bolt
 to fix to pcb